- Open the front door combination lock. When the door is open, place a strip of tape across
 the door jamb strike to prevent the door from self-locking. Use the hex key at right of rear
 door to unlock push bar. The key to the rear door lock is in the outside key vault.
- 2. Turn on the lights.
- 3. Put your name tag into the monitors ID nametag holder on the monitor's desk.
- 4. Update the woodshop sign-in log located on the monitor shelf; if sheet is almost full, start a new sheet. Make sure the current date is recorded on top of sheet.
- 5. Press the green "START" on the power switch to power up the shop.
- 6. Turn ON air compressor.
- 7. Press "ON" button on remote in desk drawer to start the main dust collector in shed.
- 8. Using a vacuum, clean the air intake filters on the ceiling air filter units.
- 9. Turn on ceiling air filter units.
- 10. Set thermostats (2). For the daytime: If heating-69 degrees, if cooling-75 degrees.
- 11. Empty all vacuums. Clean the filter inside each vacuum.
- 12. Check dust collector bag for planer/jointer and empty if needed.
- 13. Check exhaust vents in all locations, all should be closed.
- 14. Check belts on 16-32 and Delta drum sander for wear and residue buildup and correct as needed.
- 15. Check the guides on the bandsaws as they are frequently in need of adjustment.
- 16. Check the sink and clean it if needed.